

Automation and Robotics

# **5150 Robotics System Software Development Kit**

User Guide  
**39644-E0**

Printed in Canada



3 0 3 9 6 4 4 E 0 0 7 0 1 ~

***Lab-Volt***<sup>®</sup>





AUTOMATION AND ROBOTICS  
5150 ROBOTICS SYSTEM  
SOFTWARE DEVELOPMENT KIT

by  
the Staff  
of  
Lab-Volt Ltd.

**Copyright © 2007 Lab-Volt Ltd.**

All rights reserved. No part of this publication may be reproduced,  
in any form or by any means, without the prior written permission  
of Lab-Volt Ltd.

**Legal Deposit – First Trimester 2007**

**ISBN 978-2-89640-105-5**

**FIRST EDITION, JANUARY 2007**

**Printed in Canada  
January 2007**

# Foreword

The Lab-Volt 5150 Software Development Kit is a USB DLL library (5150USB.DLL) provided as an abstraction layer between the end-user application and the actual low-level communication protocol from and to the USB Controller.

This library provides simple function calls to control the Lab-Volt 5150 Robot. It also manages the USB low-level communications, as well as error handling.

The prototypes of all the exported functions and some required constants are provided in the file "5150USB.h".

A \*.LIB file named "5150USB.LIB" is also provided to allow static linking of the library to the end user application.



# Index

DLLCloseDevice .....	4
DLLDefaultCalib .....	37
DLLDisableMotors .....	14
DLLEnableMotors .....	13
DLLGetAllCurrentPosition .....	34
DLLGetDesiredPosition .....	19
DLLGetDevicePortNumber .....	1
DLLGetFrequency .....	23
DLLGetHardwareInfo .....	27
DLLGetPosition .....	17
DLLGetSelectStatus .....	11
DLLGetSolenoidOutput .....	10
DLLGetSwitch .....	8
DLLGetTTLInput .....	7
DLLGetTTLOutput .....	6
DLLGetUpdateStatus .....	30
DLLHardHome .....	26
DLLIsDeviceOpen .....	2
DLLMotorRunStatus .....	33
DLLMoveMotor .....	15
DLLMoveToCalibPos .....	35
DLLOpenDevice .....	3
DLLResetBoard .....	12
DLLResetDesiredPosition .....	20
DLLRunMotors .....	24
DLLSaveCalib .....	36
DLLSetDesiredOffset .....	21
DLLSetDesiredPosition .....	18
DLLSetFrequency .....	22
DLLSetPosition .....	16
DLLSetSelectMonitor .....	32
DLLSetSolenoidOutput .....	9
DLLSetTTLOutput .....	5
DLLStopMotors .....	25
DLLTerminateUpdate .....	31
DLLUpdateFirmware .....	29
REVISION HISTORY .....	38



# 5150 Robotics System Software Development Kit

## **DLLGetDevicePortNumber**

Retrieves the COM port number of the first CP210x USB device connected to the computer.

```
long __stdcall DLLGetDevicePortNumber( void );
```

### **Parameters**

This function has no parameters.

### **Return Values**

The COM port number (e.g.: 6, device on COM6).

Returns (-1), no device found.

**Header:** 5150USB.h

### **! Requirements**

None

### **+ See Also**

[DLLOpenDevice](#), [DLLCloseDevice](#)

# 5150 Robotics System Software Development Kit

## **DLLIsDeviceOpen**

Tests if a device has already been opened by a previous call to DLLOpenDevice.

```
long __stdcall DLLGetDevicePortNumber( void );
```

### **Parameters**

This function has no parameters.

### **Return Values**

DLL_ERROR_NO_DEVICE	No device open
DLL_ERROR_FILE_WRITE	Write operation failed
DLL_SUCCESS	Device open and available

**Header:** 5150USB.h

### **! Requirements**

None

### **+ See Also**

DLLOpenDevice, DLLCloseDevice

# 5150 Robotics System Software Development Kit

## **DLLOpenDevice**

Tries to find a 5150 USB controller connected to the system and enables the communication with it for later calls.

```
long __stdcall DLLOpenDevice( void );
```

### **Parameters**

This function has no parameters.

### **Return Values**

DLL_ERROR_NO_DEVICE	No device found
DLL_SUCCESS	Device open and available

**Header:** 5150USB.h

### **! Requirements**

None

### **+ See Also**

DLLIsDeviceOpen, DLLCloseDevice

# 5150 Robotics System Software Development Kit

## **DLLCloseDevice**

Closes the handle open to a 5150 USB controller device. You should call DLLCloseDevice at the end of your application to free allocated system resources.

```
long __stdcall DLLCloseDevice( void );
```

### **Parameters**

This function has no parameters.

### **Return Values**

DLL_ERROR_NO_DEVICE	No device open
DLL_SUCCESS	Device now closed

**Header:** 5150USB.h

### **! Requirements**

None

### **+ See Also**

DLLIsDeviceOpen, DLLOpenDevice

# 5150 Robotics System Software Development Kit

## DLLSetTTLOutput

Updates the output pattern of one of the four TTL outputs on the 5150 Robot.

```
long __stdcall DLLSetTTLOutput( BYTE byOutputId, BYTE byState );
```

### Parameters

byOutputId                   The Output ID (0...3)

The Output IDs are:

0x00 = TTL Output 1 (BROWN)

0x01 = TTL Output 2 (RED)

0x02 = TTL Output 3 (ORANGE)

0x03 = TTL Output 4 (YELLOW)

byState                      The Desired State

TRUE  0x01

FALSE 0x00

### Return Values

DLL\_SUCCESS                 If successful

DLL\_ERROR\_NO\_DEVICE        No device open

DLL\_ERROR\_FILE\_WRITE      Write operation failed

DLL\_ERROR\_FILE\_READ        Read operation failed

DLL\_ERROR\_BAD\_REPLY        Bad first character reply

**Header:** 5150USB.h

### ! Requirements

Communication must first be opened with DLLOpenDevice.

### + See Also

DLLGetTTLOutput

# 5150 Robotics System Software Development Kit

## **DLLGetTTLOutput**

Retrieves the current state of one of the four TTL outputs on the 5150 Robot.

```
long __stdcall DLLGetTTLOutput( BYTE byOutputId, BYTE *pbyState );
```

### **Parameters**

byOutputId                   The Output ID (0...3)

The Output IDs are:

0x00 = TTL Output 1 (BROWN)

0x01 = TTL Output 2 (RED)

0x02 = TTL Output 3 (ORANGE)

0x03 = TTL Output 4 (YELLOW)

\*pbyState                   A pointer to a BYTE (8-bit) variable for the state

TRUE  0x01

FALSE 0x00

### **Return Values**

DLL\_SUCCESS                 If successful

DLL\_ERROR\_NO\_DEVICE         No device open

DLL\_ERROR\_FILE\_WRITE         Write operation failed

DLL\_ERROR\_FILE\_READ         Read operation failed

DLL\_ERROR\_BAD\_REPLY         Bad first character reply

**Header:** 5150USB.h

### **! Requirements**

Communication must first be opened with DLLOpenDevice.

### **+ See Also**

DLLSetTTLOutput

# 5150 Robotics System Software Development Kit

## DLLGetTTLInput

Retrieves the current state of one of the four TTL inputs on the 5150 Robot.

```
long __stdcall DLLGetTTLInput( BYTE byInputId, BYTE *pbyState );
```

### Parameters

byInputId                                  The Input ID (0...3)

The Input IDs are:

0x00 = TTL Input 1 (BROWN)

0x01 = TTL Input 2 (RED)

0x02 = TTL Input 3 (ORANGE)

0x03 = TTL Input 4 (YELLOW)

\*pbyState                                  A pointer to a BYTE (8-bit) variable for the state

TRUE  0x01

FALSE 0x00

### Return Values

DLL\_SUCCESS                                If successful

DLL\_ERROR\_NO\_DEVICE                      No device open

DLL\_ERROR\_FILE\_WRITE                     Write operation failed

DLL\_ERROR\_FILE\_READ                      Read operation failed

DLL\_ERROR\_BAD\_REPLY                     Bad first character reply

**Header:** 5150USB.h

### ! Requirements

Communication must first be opened with DLLOpenDevice.

### + See Also

DLLSetTTLOutput

# 5150 Robotics System Software Development Kit

## DLLGetSwitch

Retrieves the current state of one of the limit switches of the 5150 Robot.

```
long __stdcall DLLGetSwitch( BYTE bySwitchId, BYTE *pbyState );
```

### Parameters

bySwitchId	The Limit Switch ID (0x09...0x0C)
------------	-----------------------------------

The Switch IDs are:

0x09 = WRIST Switch

0x0A = FOREARM Switch

0x0B = UPPER ARM Switch

0x0C = BASE Switch

*pbyState	A pointer to a BYTE (8-bit) variable for the state
-----------	----------------------------------------------------

TRIGGERED	0x01
-----------	------

UNTRIGGERED	0x00
-------------	------

### Return Values

DLL_SUCCESS	If successful
DLL_ERROR_NO_DEVICE	No device open
DLL_ERROR_FILE_WRITE	Write operation failed
DLL_ERROR_FILE_READ	Read operation failed
DLL_ERROR_BAD_REPLY	Bad first character reply

**Header:** 5150USB.h

### ! Requirements

Communication must first be opened with DLLOpenDevice.

# 5150 Robotics System Software Development Kit

## DLLSetSolenoidOutput

Updates one of the four selected solenoid outputs on the 5150 Robot.

```
long __stdcall DLLSetSolenoidOutput( BYTE bySolenoidId, BYTE byState );
```

### Parameters

bySolenoidId      The Solenoid ID (0...3)

The Solenoids IDs are:

0x00 = Solenoid Output 1

0x01 = Solenoid Output 2

0x02 = Solenoid Output 3

0x03 = Solenoid Output 4

byState      The Desired State

TRUE      0x01

FALSE      0x00

### Return Values

DLL\_SUCCESS      If successful

DLL\_ERROR\_NO\_DEVICE      No device open

DLL\_ERROR\_FILE\_WRITE      Write operation failed

DLL\_ERROR\_FILE\_READ      Read operation failed

DLL\_ERROR\_BAD\_REPLY      Bad first character reply

**Header:** 5150USB.h

### ! Requirements

Communication must first be opened with DLLOpenDevice.

### + See Also

DLLGetSolenoidOutput

# 5150 Robotics System Software Development Kit

## DLLGetSolenoidOutput

Retrieves the current state of one of the 4 solenoid outputs on the 5150 Robot.

```
long __stdcall DLLGetSolenoidOutput( BYTE bySolenoidId, BYTE *pbyState );
```

### Parameters

bySolenoidId      The Solenoid ID (0...3)

The Solenoids IDs are:

0x00 = Solenoid Output 1

0x01 = Solenoid Output 2

0x02 = Solenoid Output 3

0x03 = Solenoid Output 4

\*pbyState      A pointer to a BYTE (8-bit) variable for the state

TRUE      0x01

FALSE      0x00

### Return Values

DLL\_SUCCESS      If successful

DLL\_ERROR\_NO\_DEVICE      No device open

DLL\_ERROR\_FILE\_WRITE      Write operation failed

DLL\_ERROR\_FILE\_READ      Read operation failed

DLL\_ERROR\_BAD\_REPLY      Bad first character reply

**Header:** 5150USB.h

### ! Requirements

Communication must first be opened with DLLOpenDevice

### + See Also

DLLSetSolenoidOutput

# 5150 Robotics System Software Development Kit

## DLLGetSelectStatus

Returns the state of the LAST SELECTED switch input (the one selected by a previous call to DLLGetSwitch).

```
long __stdcall DLLGetSelectStatus( BYTE *pbyState );
```

### Parameters

*pbyState	A pointer to a BYTE (8-bit) variable for the state
-----------	----------------------------------------------------

TRIGGERED	0x01
-----------	------

UNTRIGGERED	0x00
-------------	------

### Return Values

DLL_SUCCESS	If successful
-------------	---------------

DLL_ERROR_NO_DEVICE	No device open
---------------------	----------------

DLL_ERROR_FILE_WRITE	Write operation failed
----------------------	------------------------

DLL_ERROR_FILE_READ	Read operation failed
---------------------	-----------------------

DLL_ERROR_BAD_REPLY	Bad first character reply
---------------------	---------------------------

**Header:** 5150USB.h

### ! Requirements

Communication must first be opened with DLLOpenDevice.

You should select the switch to monitor by calling DLLGetSwitch at least once.

### + See Also

DLLGetSwitch

# 5150 Robotics System Software Development Kit

## **DLLResetBoard**

Performs a reset of the motor interface board and verifies that it is ready and in working order.

```
long __stdcall DLLResetBoard( void )
```

### **Parameters**

This function has no parameters.

### **Return Values**

DLL_SUCCESS	If successful
DLL_ERROR_NO_DEVICE	No device open
DLL_ERROR_FILE_WRITE	Write operation failed
DLL_ERROR_FILE_READ	Read operation failed
DLL_ERROR_BAD_REPLY	Bad first character reply or interface not responding

**Header:** 5150USB.h

### **! Requirements**

None

# 5150 Robotics System Software Development Kit

## **DLLEnableMotors**

Enables the motor drivers on the motor interface board.

```
long __stdcall DLLEnableMotors( void )
```

### **Parameters**

This function has no parameters.

### **Return Values**

DLL_SUCCESS	If successful
DLL_ERROR_NO_DEVICE	No device open
DLL_ERROR_FILE_WRITE	Write operation failed
DLL_ERROR_FILE_READ	Read operation failed
DLL_ERROR_BAD_REPLY	Bad first character reply

**Header:** 5150USB.h

### **! Requirements**

The communication must first be opened with DLLOpenDevice

### **+ See Also**

DLLDisableMotors

# 5150 Robotics System Software Development Kit

## **DLLDisableMotors**

Disables the motor drivers on the motor interface board.

```
long __stdcall DLLDisableMotors( void );
```

### **Parameters**

This function has no parameters.

### **Return Values**

DLL_SUCCESS	If successful
DLL_ERROR_NO_DEVICE	No device open
DLL_ERROR_FILE_WRITE	Write operation failed
DLL_ERROR_FILE_READ	Read operation failed
DLL_ERROR_BAD_REPLY	Bad first character reply

**Header:** 5150USB.h

### **! Requirements**

The communication must first be opened with DLLOpenDevice

### **+ See Also**

DLLEnableMotors

# 5150 Robotics System Software Development Kit

## DLLMoveMotor

Makes a motor turn a single step in the desired direction.

```
long __stdcall DLLMoveMotor( BYTE byMotorId, BYTE byDirection );
```

### Parameters

byMotorId	The ID of the motor (0...6)
-----------	-----------------------------

The Motor IDs are:

0x00 = MOTOR\_GRIPPER

0x01 = MOTOR\_WRIST1

0x02 = MOTOR\_WRIST2

0x03 = MOTOR\_FOREARM

0x04 = MOTOR\_SHOULDER

0x05 = MOTOR\_BASE

0x06 = MOTOR\_EXTERNAL

byDirection	The direction flag
-------------	--------------------

0x00 = DIR\_BACKWARD

0x01 = DIR\_FORWARD

### Return Values

DLL_SUCCESS	If successful
DLL_ERROR_NO_DEVICE	No device open
DLL_ERROR_FILE_WRITE	Write operation failed
DLL_ERROR_FILE_READ	Read operation failed
DLL_ERROR_BAD_REPLY	Bad first character reply

**Header:** 5150USB.h

### ! Requirements

Communication must first be opened with DLLOpenDevice.

# 5150 Robotics System Software Development Kit

## DLLSetPosition

Sets the current position counter of a specific motor.

```
long __stdcall DLLSetPosition( BYTE byMotorId, int sPosition );
```

### Parameters

byMotorId	The ID of the motor (0...6)
-----------	-----------------------------

The Motor IDs are:

0x00 = MOTOR\_GRIPPER

0x01 = MOTOR\_WRIST1

0x02 = MOTOR\_WRIST2

0x03 = MOTOR\_FOREARM

0x04 = MOTOR\_SHOULDER

0x05 = MOTOR\_BASE

0x06 = MOTOR\_EXTERNAL

sPosition	A 32-bit signed position value
-----------	--------------------------------

### Return Values

DLL_SUCCESS	If successful
DLL_ERROR_NO_DEVICE	No device open
DLL_ERROR_FILE_WRITE	Write operation failed
DLL_ERROR_FILE_READ	Read operation failed
DLL_ERROR_BAD_REPLY	Bad first character reply

**Header:** 5150USB.h

### ! Requirements

Communication must first be opened with DLLOpenDevice.

### + See Also

DLLGetPosition, DLLSetDesiredPosition, DLLGetDesiredPosition

# 5150 Robotics System Software Development Kit

## DLLGetPosition

Returns the current position counter of a specific motor.

```
long __stdcall DLLGetPosition( BYTE byMotorId, int *psPosition );
```

### Parameters

byMotorId	The ID of the motor (0...6)
-----------	-----------------------------

The Motor IDs are:

0x00 = MOTOR\_GRIPPER

0x01 = MOTOR\_WRIST1

0x02 = MOTOR\_WRIST2

0x03 = MOTOR\_FOREARM

0x04 = MOTOR\_SHOULDER

0x05 = MOTOR\_BASE

0x06 = MOTOR\_EXTERNAL

*psPosition	A pointer to a 32-bit signed variable to receive the position
-------------	---------------------------------------------------------------

### Return Values

DLL_SUCCESS	If successful
DLL_ERROR_NO_DEVICE	No device open
DLL_ERROR_FILE_WRITE	Write operation failed
DLL_ERROR_FILE_READ	Read operation failed
DLL_ERROR_BAD_REPLY	Bad first character reply

**Header:** 5150USB.h

### ! Requirements

Communication must first be opened with DLLOpenDevice.

### + See Also

DLLSetPosition, DLLSetDesiredPosition, DLLGetDesiredPosition

# 5150 Robotics System Software Development Kit

## DLLSetDesiredPosition

Defines the position you want a motor to go to.

```
long __stdcall DLLSetDesiredPosition( BYTE byMotorId, int sPosition );
```

### Parameters

byMotorId	The ID of the motor (0...6)
-----------	-----------------------------

The Motor IDs are:

0x00 = MOTOR\_GRIPPER

0x01 = MOTOR\_WRIST1

0x02 = MOTOR\_WRIST2

0x03 = MOTOR\_FOREARM

0x04 = MOTOR\_SHOULDER

0x05 = MOTOR\_BASE

0x06 = MOTOR\_EXTERNAL

sPosition	A 32-bit signed value for the target position
-----------	-----------------------------------------------

### Return Values

DLL_SUCCESS	If successful
DLL_ERROR_NO_DEVICE	No device open
DLL_ERROR_FILE_WRITE	Write operation failed
DLL_ERROR_FILE_READ	Read operation failed
DLL_ERROR_BAD_REPLY	Bad first character reply

**Header:** 5150USB.h

### ! Requirements

Communication must first be opened with DLLOpenDevice.

### + See Also

DLLGetDesiredPosition

# 5150 Robotics System Software Development Kit

## DLLGetDesiredPosition

Returns the target position for a specific motor.

```
long __stdcall DLLGetDesiredPosition( BYTE byMotorId, int *psPosition );
```

### Parameters

byMotorId	The ID of the motor (0...6)
-----------	-----------------------------

The Motor IDs are:

0x00 = MOTOR\_GRIPPER

0x01 = MOTOR\_WRIST1

0x02 = MOTOR\_WRIST2

0x03 = MOTOR\_FOREARM

0x04 = MOTOR\_SHOULDER

0x05 = MOTOR\_BASE

0x06 = MOTOR\_EXTERNAL

*psPosition	A pointer to a 32-bit signed variable to receive the target position
-------------	----------------------------------------------------------------------

### Return Values

DLL_SUCCESS	If successful
DLL_ERROR_NO_DEVICE	No device open
DLL_ERROR_FILE_WRITE	Write operation failed
DLL_ERROR_FILE_READ	Read operation failed
DLL_ERROR_BAD_REPLY	Bad first character reply

**Header:** 5150USB.h

### ! Requirements

Communication must first be opened with DLLOpenDevice.

### + See Also

DLLSetDesiredPosition

# 5150 Robotics System Software Development Kit

## **DLLResetDesiredPosition**

Clears the previously defined motor motions.

```
long __stdcall DLLResetDesiredPosition( void );
```

### **Parameters**

This function has no parameters.

### **Return Values**

DLL_SUCCESS	If successful
DLL_ERROR_NO_DEVICE	No device open
DLL_ERROR_FILE_WRITE	Write operation failed
DLL_ERROR_FILE_READ	Read operation failed
DLL_ERROR_BAD_REPLY	Bad first character reply

**Header:** 5150USB.h

### **! Requirements**

Communication must first be opened with DLLOpenDevice.

### **+ See Also**

DLLSetDesiredPosition, DLLGetDesiredPosition

# 5150 Robotics System Software Development Kit

## DLLSetDesiredOffset

Lets you specify a new position based on an offset from the current location.

```
long __stdcall DLLSetDesiredOffset( BYTE byMotorId, int sOffset );
```

### Parameters

byMotorId	The ID of the motor (0...6)
-----------	-----------------------------

The Motor IDs are:

0x00 = MOTOR\_GRIPPER

0x01 = MOTOR\_WRIST1

0x02 = MOTOR\_WRIST2

0x03 = MOTOR\_FOREARM

0x04 = MOTOR\_SHOULDER

0x05 = MOTOR\_BASE

0x06 = MOTOR\_EXTERNAL

sOffset	A 32-bit signed offset value
---------	------------------------------

### Return Values

DLL_SUCCESS	If successful
DLL_ERROR_NO_DEVICE	No device open
DLL_ERROR_FILE_WRITE	Write operation failed
DLL_ERROR_FILE_READ	Read operation failed
DLL_ERROR_BAD_REPLY	Bad first character reply

**Header:** 5150USB.h

### ! Requirements

Communication must first be opened with DLLOpenDevice.

# 5150 Robotics System Software Development Kit

## DLLSetFrequency

Sets the pulse frequency for a specified motor.

```
long __stdcall DLLSetFrequency( BYTE byMotorId, unsigned short usFrequency );
```

### Parameters

byMotorId                  The ID of the motor (0...6)

The Motor IDs are:

0x00 = MOTOR\_GRIPPER

0x01 = MOTOR\_WRIST1

0x02 = MOTOR\_WRIST2

0x03 = MOTOR\_FOREARM

0x04 = MOTOR\_SHOULDER

0x05 = MOTOR\_BASE

0x06 = MOTOR\_EXTERNAL

usFrequency                A 16-bit unsigned value for the frequency

### Return Values

DLL_SUCCESS	If successful
DLL_ERROR_NO_DEVICE	No device open
DLL_ERROR_FILE_WRITE	Write operation failed
DLL_ERROR_FILE_READ	Read operation failed
DLL_ERROR_BAD_REPLY	Bad first character reply

**Header:** 5150USB.h

### ! Requirements

Communication must first be opened with DLLOpenDevice.

### + See Also

DLLGetFrequency

# 5150 Robotics System Software Development Kit

## DLLGetFrequency

Returns the pulse frequency for a specified motor.

```
long __stdcall DLLGetFrequency( BYTE byMotorId, unsigned short *pusFrequency );
```

### Parameters

byMotorId	The ID of the motor (0...6)
-----------	-----------------------------

The Motor IDs are:

0x00 = MOTOR\_GRIPPER

0x01 = MOTOR\_WRIST1

0x02 = MOTOR\_WRIST2

0x03 = MOTOR\_FOREARM

0x04 = MOTOR\_SHOULDER

0x05 = MOTOR\_BASE

0x06 = MOTOR\_EXTERNAL

*pusFrequency	A pointer to a 16-bit unsigned value for the returned frequency value
---------------	-----------------------------------------------------------------------

### Return Values

DLL_SUCCESS	If successful
DLL_ERROR_NO_DEVICE	No device open
DLL_ERROR_FILE_WRITE	Write operation failed
DLL_ERROR_FILE_READ	Read operation failed
DLL_ERROR_BAD_REPLY	Bad first character reply

**Header:** 5150USB.h

### ! Requirements

Communication must first be opened with DLLOpenDevice.

### + See Also

DLLSetFrequency

# 5150 Robotics System Software Development Kit

## DLLRunMotors

Starts all motors that have a target position different than their current position.

```
long __stdcall DLLRunMotors( void );
```

### Parameters

This function has no parameters.

### Return Values

DLL_SUCCESS	If successful
DLL_ERROR_NO_DEVICE	No device open
DLL_ERROR_FILE_WRITE	Write operation failed
DLL_ERROR_FILE_READ	Read operation failed
DLL_ERROR_BAD_REPLY	Bad first character reply

**Header:** 5150USB.h

### ! Requirements

Communication must first be opened with DLLOpenDevice.

You should first set the destination position and frequency of the motors with DLLSetDesiredPosition and DLLSetFrequency.

### + See Also

DLLStopMotors, DLLSetDesiredPosition, DLLSetFrequency

# 5150 Robotics System Software Development Kit

## **DLLStopMotors**

Stops the motors. This function will return only when the movement has stopped.

```
long __stdcall DLLStopMotors( void );
```

### **Parameters**

This function has no parameters.

### **Return Values**

DLL_SUCCESS	If successful
DLL_ERROR_NO_DEVICE	No device open
DLL_ERROR_FILE_WRITE	Write operation failed
DLL_ERROR_FILE_READ	Read operation failed
DLL_ERROR_BAD_REPLY	Bad first character reply

**Header:** 5150USB.h

### **! Requirements**

Communication must first be opened with DLLOpenDevice.

### **+ See Also**

DLLRunMotors

# 5150 Robotics System Software Development Kit

## **DLLHardHome**

One-step command used to return the robot to its home position. This function returns only once the procedure is completed, which could take as long as 60 seconds.

```
long __stdcall DLLHardHome( void );
```

### **Parameters**

This function has no parameters.

### **Return Values**

DLL_SUCCESS	If successful
DLL_ERROR_NO_DEVICE	No device open
DLL_ERROR_FILE_WRITE	Write operation failed
DLL_ERROR_FILE_READ	Read operation failed
DLL_ERROR_BAD_REPLY	Bad first character reply

**Header:** 5150USB.h

### **! Requirements**

Communication must first be opened with DLLOpenDevice.

# 5150 Robotics System Software Development Kit

## DLLGetHardwareInfo

Returns the firmware revision number and the numerous diagnostic codes. You should call DLLGetHardwareInfo to get more information about the problem(s) that might cause a DLL\_ERROR\_BAD\_REPLY to be returned in response to any other function calls.

```
long __stdcall DLLGetHardwareInfo(void *pvData );
```

### Parameters

*pvData	A pointer to a BYTE array of at least 20 bytes
---------	------------------------------------------------

*pvData+0	USB controller firmware major revision number
-----------	-----------------------------------------------

*pvData+1	USB controller firmware minor revision number
-----------	-----------------------------------------------

*pvData+2	Last recorded error code producing a NAK
-----------	------------------------------------------

0x00	No error yet!
------	---------------

0x01	Firmware in one or more time base generators (PIC12F629) not matching the reference code in memory
------	----------------------------------------------------------------------------------------------------

0x02	Unable to reprogram the 7 time base generators (PIC12)
------	--------------------------------------------------------

0x03	MIB interface not connected or OFF
------	------------------------------------

0x04	Received command frame not RECOGNIZED
------	---------------------------------------

0x05	MotorID too high (>6)
------	-----------------------

0x06	Problem encountered in attempting to start INT_EXT for motor run
------	------------------------------------------------------------------

0x07	Unable to do a MIB_Port_Write (a time-out error occurred)
------	-----------------------------------------------------------

0x08	MIB_Port_Wait_For_Busy_Low() function timed-out
------	-------------------------------------------------

*pvData+3	Each bit represents a faulty PIC12 time base generator, when any.
-----------	-------------------------------------------------------------------

# 5150 Robotics System Software Development Kit

## **Return Values**

DLL_SUCCESS	If successful
DLL_ERROR_NO_DEVICE	No device open
DLL_ERROR_FILE_WRITE	Write operation failed
DLL_ERROR_FILE_READ	Read operation failed
DLL_ERROR_BAD_REPLY	Bad first character reply

**Header:** 5150USB.h

## **! Requirements**

Communication must first be opened with DLLOpenDevice.

# 5150 Robotics System Software Development Kit

## **DLLUpdateFirmware**

Opens the specified INTEL-HEX file, and then starts the update thread that will do the actual update. After calling DLLUpdateFirmware, you should call DLLGetUpdateStatus to get information about the update process.

```
long __stdcall DLLUpdateFirmware( char *pszFileName );
```

### **Parameters**

\*pszFileName A pointer to a string containing the complete PATH and FILENAME of the updated INTEL-HEX file

### **Return Values**

DLL\_SUCCESS If successful

DLL\_ERROR\_FILE\_READ Could not open the file. Update aborted.

**Header:** 5150USB.h

### **! Requirements**

None

### **+ See Also**

DLLGetUpdateStatus

# 5150 Robotics System Software Development Kit

## DLLGetUpdateStatus

Gets the status of the firmware update process. By checking the value returned in pnStatus, you can check if the update is completed. PnLineCount and pnMaxCount can be used to compute the completion of the update process.

```
long __stdcall DLLGetUpdateStatus( int *pnStatus, int *pnLineCount, int *pnMaxCount );
```

### Parameters

*pnStatus	A pointer to an integer for a status code:
	DLL_STATUS_UPDATE_WORKING
	Update thread still running
	DLL_STATUS_UPDATE_ERROR
	Firmware update error
	DLL_STATUS_UPDATE_SUCCESS
	Firmware update completed

*pnLineCount	Last line updated by the thread
--------------	---------------------------------

*pnMaxCount	Total number of lines in the file
-------------	-----------------------------------

### Return Values

DLL_SUCCESS	Always
-------------	--------

**Header:** 5150USB.h

### ! Requirements

None

### + See Also

DLLUpdateFirmware

# 5150 Robotics System Software Development Kit

## **DLLTerminateUpdate**

Aborts the firmware update process. Normally, you should not call this function. The firmware update will complete by itself and the status returned by DLLGetUpdateStatus will change to DLL\_STATUS\_UPDATE\_SUCCESS.

If you abort the firmware update, the USB controller firmware will have to be successfully updated to be operational again.

```
long __stdcall DLLTerminateUpdate( void )
```

### **Parameters**

This function has no parameters.

### **Return Values**

DLL_SUCCESS	Always
-------------	--------

**Header:** 5150USB.h

### **! Requirements**

None

### **+ See Also**

DLLUpdateFirmware, DLLGetUpdateStatus

# 5150 Robotics System Software Development Kit

## **DLLSetSelectMonitor**

Sets the state of the SELECT line (limit switches) that will stop the motors.

```
long __stdcall DLLSetSelectMonitor( BYTE byState );
```

### **Parameters**

byState	The state to monitor:
	TRIGGERED 0x01
	UNTRIGGERED 0x00

### **Return Values**

DLL_SUCCESS	If successful
DLL_ERROR_NO_DEVICE	No device open
DLL_ERROR_FILE_WRITE	Write operation failed
DLL_ERROR_FILE_READ	Read operation failed
DLL_ERROR_BAD_REPLY	Bad first character reply

**Header:** 5150USB.h

### **! Requirements**

Communication must first be opened with DLLOpenDevice.

### **+ See Also**

DLLGetSwitch, DLLGetSelectStatus

# 5150 Robotics System Software Development Kit

## DLLMotorRunStatus

Returns the state of the "Running-Flag" byte, this flag indicating if one or more motors are running.

```
long __stdcall DLLMotorRunStatus( BYTE *pbyStatus );
```

### Parameters

*pbyStatus	Pointer to a BYTE to receive the status:
0	All motors stopped
n	Each bit set to "1" represents a motor that is still running.

### Return Values

DLL_SUCCESS	If successful
DLL_ERROR_NO_DEVICE	No device open
DLL_ERROR_FILE_WRITE	Write operation failed
DLL_ERROR_FILE_READ	Read operation failed
DLL_ERROR_BAD_REPLY	Bad first character reply

**Header:** 5150USB.h

### ! Requirements

Communication must first be opened with DLLOpenDevice.

### + See Also

DLLRunMotors

# 5150 Robotics System Software Development Kit

## DLLGetAllCurrentPosition

Returns the "Running-Flag" state (TRUE/FALSE) and the current position of all 7 motors.

```
long __stdcall DLLGetAllCurrentPosition(BYTE * runningMotorFlag, int * positions);
```

### Parameters

*runningMotorFlag	Pointer to a BYTE to receive the running flag state.
-------------------	------------------------------------------------------

0x00 All motors stopped

0x01 At least one motor running

*positions	Pointer to a 32-bit signed variable to receive the positions of the 7 motors.
------------	-------------------------------------------------------------------------------

position[0] Position of motor 1

position[1] Position of motor 2

...

position[6] Position of motor 7

### Return Values

DLL_SUCCESS	If successful
-------------	---------------

DLL_ERROR_NO_DEVICE	No device open
---------------------	----------------

DLL_ERROR_FILE_WRITE	Write operation failed
----------------------	------------------------

DLL_ERROR_FILE_READ	Read operation failed
---------------------	-----------------------

DLL_ERROR_BAD_REPLY	Bad first character reply
---------------------	---------------------------

DLL_ERROR_EMPTY_COMMAND	One of the function parameters is NULL
-------------------------	----------------------------------------

**Header:** 5150USB.h

### ! Requirements

Communication must first be opened with DLLOpenDevice.

### + See Also

DLLMotorRunStatus

# 5150 Robotics System Software Development Kit

## DLLMoveToCalibPos

Moves the robot to a predefined calibration position. This method is useful in helping the user to put the robot in the calibration position.

```
long __stdcall DLLMoveToCalibPos( void );
```

### Parameters

This function has no parameters.

### Return Values

DLL_SUCCESS	If successful
DLL_ERROR_NO_DEVICE	No device open
DLL_ERROR_FILE_WRITE	Write operation failed
DLL_ERROR_FILE_READ	Read operation failed
DLL_ERROR_BAD_REPLY	Bad first character reply

**Header:** 5150USB.h

### ! Requirements

Communication must first be opened with DLLOpenDevice.  
The robot must first be hard homed before using this function.

### + See Also

DLLSaveCalib, DLLDefaultCalib

# 5150 Robotics System Software Development Kit

## DLLSaveCalib

This function saves the calibration offsets from the robot's current calibration position. It will first move the robot to the ideal home position, then do a hard home, and finally save the offsets in the controller memory.

```
long __stdcall DLLSaveCalib( void );
```

### Parameters

This function has no parameters.

### Return Values

DLL_SUCCESS	If successful
DLL_ERROR_NO_DEVICE	No device open
DLL_ERROR_FILE_WRITE	Write operation failed
DLL_ERROR_FILE_READ	Read operation failed
DLL_ERROR_BAD_REPLY	Bad first character reply

**Header:** 5150USB.h

### ! Requirements

Communication must first be opened with DLLOpenDevice.  
The robot must first be hard homed before using this function.

### + See Also

DLLMoveToCalibPos, DLLDefaultCalib

# 5150 Robotics System Software Development Kit

## **DLLDefaultCalib**

Resets the calibration offsets to 0.

```
long __stdcall DLLDefaultCalib( void );
```

### **Parameters**

This function has no parameters.

### **Return Values**

DLL\_SUCCESS    Always

**Header:** 5150USB.h

### **! Requirements**

None

### **+ See Also**

DLLMoveToCalibPos, DLLSaveCalib

# 5150 Robotics System Software Development Kit

## **REVISION HISTORY**

JANUARY 18th, 2005: Initial Release

SEPTEMBER 12th, 2005: Modified documentation for the DLLMotorRunStatus command

JUNE 20th, 2006: Calibration methods added

AUTOMATION AND ROBOTICS  
5150 ROBOTICS SYSTEM  
SOFTWARE DEVELOPMENT KIT  
39644-E0  
First Edition: January 2007  
Printed: January 2007

### We Value Your Opinion!

#### COMMENTS

If you have any comments on this guide, please take a few minutes to write them down in the following lines and return this sheet to the address indicated on verso. Thank you! Your comments will enable us to produce better manuals.

---

---

---

---

---

---

---

---

---

---

#### PUBLICATION ERRORS AND COMMENTS

Please enclose photocopies of pages where errors were found and indicate the modifications that should be carried out.

If you want to receive the corrected pages, please fill in the identification section.

#### BACKGROUND INFORMATION

- Instructor       Student  
 High School     Vocational     Technical Institute     University

#### IDENTIFICATION

NAME \_\_\_\_\_

ADDRESS \_\_\_\_\_

PHONE \_\_\_\_\_ FAX \_\_\_\_\_

Fold and tape

Fold and tape

**LAB-VOLT LTD.  
Technical Publications Department  
675, rue du Carbone  
Québec (Québec) G2N 2K7  
Canada**

C  
u  
t  
a  
i  
o  
n  
g  
l  
i  
n  
e

Fold and tape

Fold and tape

