ECE435: Network Engineering – Homework 10 Link Layer and Ethernet

Due: Friday, 11 April 2025, 5:00pm

For this homework short answers will suffice.

To submit, create a document with your answers (text, pdf, libreoffice, MS Office if you must) and e-mail them to *vincent.weaver@maine.edu* by the homework deadline. Title your e-mail "ECE435 Homework 10" and be sure your name is included in the document.

1. Ethernet Header (4pts)

From previous homeworks, we used tcpdump to gather that output of our client program doing a simple web request. sudo tcpdump port 80 -xe -i eth0 -XX

(a) We now have enough knowledge to decode the entire frame. Use classnotes or the IEEE 802.3 specification to debug the Ethernet fields. Note that tcpdump is not able to capture the preamble/SFD or FCS (checksum) values.

BEGIN Ethernet HEADER	Name of Field	Decoded Value
0x0000: 0013 3b10 667f		
0x0006: b827 ebaf 3711		
0x000c: 0800		

- (b) Who owns the OUI of the MAC addresses in the source and destination? You can use a tool such as https://www.wireshark.org/tools/oui-lookup.html to find this info.
- (c) In an earlier homework we decoded the IPv4 part of this frame and saw its eventual destination is 130.111.46.127. This is not on the local network. Is the destination MAC address that of 130.111.46.127? If not, what machine does the MAC address correspond to?

2. Protocol Mystery (2pts)

You run tcpdump and you see packets like this.

- (a) What protocol is this?
- (b) What is it used for?

3. Answer the following questions (2pts)

- (a) Why did Ethernet win out over TokenRing?
- (b) Why is the minimum size of an Ethernet frame 64 bytes?
- (c) Why is the maximum size of an Ethernet frame 1500 bytes?
- (d) What does your Ethernet card do to a frame if it calculates an invalid CRC?

4. Investigating an Ethernet Interface (2pts)

If you have access to a Linux machine with a wired ethernet connection, we will gather some info on your Ethernet device. You should know enough now to interpret the results.

If you don't have a wired Linux interface, look at the last two pages of this document, I've provided some sample results you can use instead.

The traditional way of gathering info on the network interface was the command /sbin/ifconfig eth0

where eth0 was traditionally the first ethernet interface in the system (depending on your Linux distibution a much more complicated name might be used for the interface).

These days if config has been deprecated and might not be installed by default. The replacement is the ip tool.

You can get similar results to if config by the commands ip addr and ip -s addr

To find out lower-level info specific to your ethernet card you can run

/sbin/ethtool eth0

(note you might have to install ethtool, it might not be there by default).

You can also find out about your card by looking at the boot messages

sudo dmesg | grep eth

Answer the following questions, either using info you gathered yourself or else from the results provided on the following pages:

- (a) What is the MAC address?
- (b) Look up the MAC owner using an OUI lookup tool. If it's your own device, does the OUI match what you'd expect?
- (c) What is the default frame size (MTU)?
- (d) How many bytes have been received (RX)?
- (e) How many bytes have been transmitted (TX)?
- (f) Has your device seen any collisions?
- (g) Has your device dropped any packets?
- (h) If the collision count is low, can you explain why that is?
- (i) What speed is your device running at?
- (j) Are you connected to a switch rather than a hub? How can you tell?

/sbin/ifconfig eth0

eth0: flags=4163<UP,BROADCAST,RUNNING,MULTICAST> mtu 1500
 inet 130.111.218.24 netmask 255.255.254.0 broadcast 130.111.219.255
 inet6 fe80::225:90ff:fee3:5734 prefixlen 64 scopeid 0x20<link>
 ether 00:25:90:e3:57:34 txqueuelen 1000 (Ethernet)
 RX packets 359075559 bytes 76137884844 (70.9 GiB)
 RX errors 0 dropped 0 overruns 13216 frame 0
 TX packets 74498857 bytes 18280085535 (17.0 GiB)
 TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
 device memory 0xfe120000-fe13ffff

ip addr

2: eth0: <BROADCAST,MULTICAST,UP,LOWER_UP> mtu 1500 qdisc mq state UP group def link/ether 00:25:90:e3:57:34 brd ff:ff:ff:ff:ff inet 130.111.218.24/23 brd 130.111.219.255 scope global dynamic eth0 valid_lft 34690sec preferred_lft 34690sec inet6 fe80::225:90ff:fee3:5734/64 scope link valid_lft forever preferred_lft forever

ip -s addr

2: eth0: <BROADCAST,MULTICAST,UP,LOWER_UP> mtu 1500 qdisc mq state UP group def link/ether 00:25:90:e3:57:34 brd ff:ff:ff:ff:ff inet 130.111.218.24/23 brd 130.111.219.255 scope global dynamic eth0 valid_lft 34657sec preferred_lft 34657sec inet6 fe80::225:90ff:fee3:5734/64 scope link valid_lft forever preferred_lft forever RX: bytes packets errors dropped overrun mcast 76139606874 359098268 0 0 0 98966998 TX: bytes packets errors dropped carrier collsns 18280800017 74503021 0 0 0 0

/sbin/ethtool eth0 Settings for eth0: Supported ports: [TP] Supported link modes: 10baseT/Half 10baseT/Full 100baseT/Half 100baseT/Full 1000baseT/Full Supported pause frame use: Symmetric Supports auto-negotiation: Yes Supported FEC modes: Not reported Advertised link modes: 10baseT/Half 10baseT/Full 100baseT/Half 100baseT/Full 1000baseT/Full Advertised pause frame use: Symmetric Advertised auto-negotiation: Yes Advertised FEC modes: Not reported Speed: 1000Mb/s Duplex: Full Auto-negotiation: on Port: Twisted Pair PHYAD: 1 Transceiver: internal MDI-X: off (auto) Supports Wake-on: pumbg Wake-on: q Current message level: 0x0000007 (7) drv probe link

Link detected: yes

```
sudo dmesg | grep eth
[
     5.289165] iqb 0000:05:00.0: added PHC on eth0
     5.289206] iqb 0000:05:00.0: eth0: (PCIe:5.0Gb/s:Width x2)
Γ
        00:25:90:e3:57:34
Γ
     5.289294] igb 0000:05:00.0: eth0: PBA No: 106100-000
Γ
     5.348648] iqb 0000:05:00.1: added PHC on eth1
     5.348689] iqb 0000:05:00.1: eth1: (PCIe:5.0Gb/s:Width x2)
Γ
        00:25:90:e3:57:35
     5.348780] igb 0000:05:00.1: eth1: PBA No: 106100-000
Γ
   31.353051] igb 0000:05:00.1 eth1: igb: eth1 NIC Link is Up
[
        1000 Mbps Full Duplex, Flow Control: RX/TX
Γ
   31.353294] IPv6: ADDRCONF(NETDEV_CHANGE): eth1: link becomes ready
[
   36.757030] igb 0000:05:00.0 eth0: igb: eth0 NIC Link is Up
        1000 Mbps Full Duplex, Flow Control: RX
    36.757240] IPv6: ADDRCONF (NETDEV_CHANGE): eth0: link becomes ready
ſ
```