

ECE 471 – Embedded Systems

Lecture 10

Vince Weaver

`https://web.eece.maine.edu/~vweaver`

`vincent.weaver@maine.edu`

24 September 2025

Announcements

- Don't forget HW#3
- HW#2 partly graded (delayed by the network outage yesterday)



HW2 Review – General

- Most people seem to be accessing the Pi OK
- Be sure to follow directions!
- Put your name in the README
- Testing. How can you test? `wc -l`



HW2 Review – C Code

- Comment your code!
- Be sure if it says print 15 lines that it does.
- Watch for off-by-one errors
- Colors seem not to be a problem.
- Also watch out for compiler warnings! (Though each compiler version might have different warnings)
- **Error handling! especially for command line parsing**



HW2 Review – Questions

- more info on ls. Looking for man. “info” or `ls --help`
- `ls -a` shows hidden files. Hidden files on UNIX
- Why use C? close to hardware, easier than assembly, etc. careful with “faster”. It often is, but give reasoning and what you are comparing (faster than python? asm?)



HW2 Review – Connecting to the Pi

- People connecting OK?
- Originally point of Pi was cheap board and you possibly already had SD card, USB-keyboard (from desktop), USB-micro charger, and HDMI cable floating around. Modern Pis more difficult, mostly the micro-HDMI cable which I don't think anyone has.
- Network? ssh? VNC? keyboard/screen? Bluetooth?



ARM Instruction Set Encodings

- ARM – 32 bit encoding
- THUMB – 16 bit encoding
- THUMB-2 – THUMB extended with 32-bit instructions
 - STM32L *only* has THUMB2
 - Original Raspberry Pis *do not* have THUMB2
 - Raspberry Pi 2/3 *does* have THUMB2
- THUMB-EE – extensions for running in JIT runtime
- AARCH64 – 64 bit. Relatively new. Completely different from ARM32




Note on 32-bit Architectures

- Push to stop supporting 32-bits on Linux and others
- x86-32 mostly still around due to games/steam
- ARM32 will hang around in Linux due to embedded
- Other companies (like Apple) drop 32-bit because they can, also it adds testing workload for software, also hardware needs more transistors/power (and testing) for 32-bit code paths



Recall the ARM32 encoding

ADD{S}<c> <Rd>, <Rn>, <Rm>{, <shift>}



Why Code Density

- Smaller code can be better
- Lower resources: Cheaper? If you can fit more features into smaller RAM or disk you can save money
- Faster? It depends. Modern chips are really hard to predict, but if your processor has Caches and you can fit better in instruction cache it can potentially speed things up a lot




Compact RISC Assembly Encodings

- A real problem on embedded systems, RISC code is not very compact
- Pretty much all embedded architectures ended up with alternate more compact encoding
- POWERPC has one, MIPS has various (look up), SH3 started that way, RISCV has C (compressed) extension
- ARM was one of the first with THUMB



THUMB

- Most instructions length 16-bit (a few 32-bit)
- Only r0-r7 accessible normally
add, cmp, mov can access high regs
- Some operands (sp, lr, pc) implicit
Can't always update sp or pc anymore.
- No prefix/conditional execution
- Only two arguments to opcodes
(some exceptions for small constants: add r0,r1,#1)
- 8-bit constants rather than 12-bit



- Limited addressing modes: $[rn,rm]$, $[rn,\#imm]$, $[pc|sp,\#imm]$
- No shift parameter ALU instructions
- Makes assumptions about “S” setting flags
(gas doesn't let you superfluously set it, causing problems if you naively move code to THUMB-2)
- new push/pop instructions (subset of ldm/stm), neg (to negate), asr, lsl, lsr, ror, bic (logic bit clear)



THUMB/ARM interworking

- See `print_string_armthumb.s`
- BX/BLX instruction to switch mode.
Sets/clears the T (thumb) flag in status register
If target is a label, *always* switchmode
If target is a register, low bit of 1 means THUMB, 0 means ARM
- Can also switch modes with `ldrm`, `ldm`, or `pop` with PC as a destination
(on armv7 can enter with ALU op with PC destination)



- Can use `.thumb` directive, `.arm` for 32-bit.



THUMB-2

- You have already used Thumb-2 w/o realizing it in ECE271
- Many ARM Cortex-M chips only support Thumb-2 and not ARM32



THUMB-2 details

- Extension of THUMB to have both 16-bit and 32-bit instructions
- The 32-bit instructions are *not* the standard 32-bit ARM instructions.
- Most 32-bit ARM instructions have 32-bit THUMB-2 equivalents *except* ones that use conditional execution. The `it` instruction was added to handle this.
- `rsc` (reverse subtract with carry) removed
- Most cannot have PC as src/dest



- Shifts in ALU instructions are by constant, cannot shift by register like in arm32
- THUMB-2 code can assemble to either ARM-32 or THUMB2

The assembly language is compatible.

Common code can be written and output changed at time of assembly.

- Instructions have “wide” and “narrow” encoding.
Can force this (add.w vs add.n).
- Need to properly indicate “s” (set flags).
On regular THUMB this is assumed.



THUMB-2 Coding

- See `test_thumb2.s`
- Use `.syntax unified` at beginning of code
- Use `.arm` or `.thumb` to specify mode



New THUMB-2 Instructions

- BFI – bit field insert
- RBIT – reverse bits
- movw/movt – 16 bit immediate loads
- TB – table branch
- IT (if/then)
- cbz – compare and branch if zero; only jumps forward



Thumb-2 12-bit immediates

```
top 4 bits 0000 -- 00000000 00000000 00000000 abcdefgh
              0001 -- 00000000 abcdefgh 00000000 abcdefgh
              0010 -- abcdefgh 00000000 abcdefgh 00000000
              0011 -- abcdefgh abcdefgh abcdefgh abcdefgh
rotate bottom 7 bits|0x80 right by top 5 bits
              01000 -- 1bcdefgh 00000000 00000000 00000000
              ...
              11111 -- 00000000 00000000 00000001 bcdefgh0
```



Generating with Compiler

- Original RASPBERRY PI DOES NOT SUPPORT THUMB2
- `gcc -S hello_world.c`
By default is arm32
- `gcc -S -march=armv5t -mthumb hello_world.c`
Creates THUMB (won't work on Raspberry Pi due to HARDFP arch)
- `-mthumb -march=armv7-a+fp` Creates THUMB2 for pi



IT (If/Then) Instruction

- Allows limited conditional execution in THUMB-2 mode.
- The directive is optional (and ignored in ARM32)
the assembler can (in-theory) auto-generate the IT instruction
- Limit of 4 instructions



Example Code

```
it cc
```

```
addcc r1,r2
```


```
itete cc
```

```
addcc r1,r2
```

```
addcs r1,r2
```


```
addcc r1,r2
```

```
addcs r1,r2
```



11 Example Code

```
        ittt cs @ If CS Then Next plus CS for next 3
discrete_char:
        ldrbcs  r4,[r3]          @ load a byte
        addcs   r3,#1            @ increment pointer
        movcs   r6,#1            @ we set r6 to one so byte
        bcs.n   store_byte       @ and store it
offset_length:
```



AARCH64

- 32-bit fixed instruction encoding
- 32 64-bit GP registers
 - x0 - x7 = args
 - x8 - x18 = temp (x8=syscall num during syscall)
 - x19-x28 = callee saved
 - x29 = frame pointer
 - x30 = link register
 - x31 = zero register or stack pointer
- PC is not a GP register



- only branches conditional
- no load/store multiple
- No thumb
- TODO: more info on differences




Code Density

- Overview from my 11 ICCD'09 paper
- Show code density for variety of architectures, recently added Thumb-2 support.
- Shows overall size, though not a fair comparison due to operating system differences on non-Linux machines



Code Density – overall




lzss compression

- Printing routine uses lzss compression
- Might be more representative of potential code density



Code Density – lzss




Put string example

```
.equ SYSCALL_EXIT,      1
.equ SYSCALL_WRITE,     4
.equ STDOUT,            1

        .globl _start
_start:
        ldr        r1,=hello
        bl         print_string           @ Print Hello World
        ldr        r1,=mystery
        bl         print_string           @
        ldr        r1,=goodbye
        bl         print_string           /* Print Goodbye */

        #=====
        # Exit
        #=====

exit:
        mov        r0,#5
        mov        r7,#SYSCALL_EXIT      @ put exit syscall number (1) in eax
        swi        0x0                   @ and exit
```




```

#=====
# print string
#=====
# Null-terminated string to print pointed to by r1
# r1 is trashed by this routine

```

```

print_string:
    push    {r0,r2,r7,r10}           @ Save r0,r2,r7,r10 on stack

    mov     r2,#0                     @ Clear Count

count_loop:
    add     r2,r2,#1                   @ increment count
    ldrb    r10,[r1,r2]                @ load byte from address r1+r2
    cmp     r10,#0                     @ Compare against 0
    bne     count_loop                 @ if not 0, loop

    mov     r0,#STDOUT                 @ Print to stdout
    mov     r7,#SYSCALL_WRITE          @ Load syscall number
    swi     0x0                       @ System call

    pop     {r0,r2,r7,r10}            @ pop r0,r2,r7,r10 from stack

    mov     pc,lr                     @ Return to address stored in

```



@ Link register

.data

```
hello:      .string "Hello_World!\n"    @ includes null at end
mystery:    .byte 63,0x3f,63,10,0        @ mystery string
goodbye:    .string "Goodbye!\n"        @ includes null at end
```

