

Prelab for Lab #8: Pulse Width Modulation and Servo Motor Control

Week of 1 April 2019

Part A – Textbook Readings / Videos

1. Read Textbook Chapter 15.3 to review pulse-width modulation.
2. For background on how the timer works, the textbook recommends the following videos (note, I haven't extensively reviewed these).

(a) PWM: <http://www.youtube.com/watch?v=zkrVHIcLGww>

Part B – Prelab assignment

In this lab we will set up the TIM1 timer and use it to generate Pulse-width modulated (PWM) signals. We will first use it to pulse the green LED on the STM board, and then we will use it to control a servo motor.

1. Settings needed to PWM the Green LED

We want to PWM the Green LED on the board. Remember it is connected to GPIOE8.

You will need to set the following fields. Write the values to mask/set. If no mask is needed you can let that blank. You can use pre-defined names for the bits rather than raw hex values.

- Set $GPIOE \rightarrow MODER$ for pin 8 to be “alternate” mode.
MASK MODER= _____
VALUE MODER= _____
- Set $GPIOE \rightarrow AFR[0]$ and $GPIOE \rightarrow AFR[1]$ for alternate function of Pin 8 to be TIM1_CH1N. You can look in Appendix I of the book to see which one this is. This should be in one of the document pdfs too but I wasn't able to find which one.
MASK AFR[0]= _____
VALUE AFR[0]= _____
MASK AFR[1]= _____
VALUE AFR[1]= _____
- Set $GPIOE \rightarrow OTYPER$ for Pin 8 to be push-pull
MASK OTYPER= _____
VALUE OTYPER= _____
- Set $GPIOE \rightarrow PUPDR$ for Pin 8 for no pull-up/pull-down
MASK PUPDR= _____
VALUE PUPDR= _____

2. Settings needed to use TIM1 for PWM mode




Figure 1: The TIM1 timer has many more configuration settings than the SysTick timer did.

Setting up the TIM1 timer has a lot more options than the SysTick timer, as you can see in Figure 1. You can find the settings in Chapter 30 of the STM manual, and also in Chapter 15.3 of the textbook (specifically example 15-4).

You will need to set the following fields. Write the values to mask/set. If no mask is needed you can let that blank. You can use pre-defined names for the bits rather than raw hex values.

- Set $TIM1 \rightarrow CR1$ for the counting direction to be up.
 MASK CR1= _____
 VALUE CR1= _____
- We will use a 4MHz MSI clock for this lab. Set the prescaler $TIM1 \rightarrow PSC$ to count at 100kHz.
 MASK PSC= _____
 VALUE PSC= _____
- Set the $TIM1 \rightarrow ARR$ register to a value that will give a period of 0.01s
 MASK ARR= _____
 VALUE ARR= _____
- Clear the OC1M field in the $TIM1 \rightarrow CCMR1$ register and select PWM Mode 1 (OC1M = 110):
 MASK CCMR1= _____
 VALUE CCMR1= _____

- Enable the Output 1 preload enable in *TIM1* – > *CCMR1*: MASK *CCMR1*=_____

VALUE *CCMR1*=_____

- Select the output polarity by clearing the *CC1NP* field in the *TIM1* – > *CCER* register:

MASK *CCMR1*=_____

VALUE *CCMR1*=_____

- Enable complementary output of Channel 1 (*CH1N*) by setting the *CC1NE* bit in *TIM1* – > *CCER*:

MASK *CCER*=_____

VALUE *CCER*=_____

- Set the main output enable (*MOE*) in *TIM1* – > *BDTR*:

MASK *BDTR*=_____

VALUE *BDTR*=_____

- Set the output compare register for channel 1 *TIM1* – > *CCR1* to have a duty cycle of 50%:

MASK *CCR1*=_____

VALUE *CCR1*=_____