

ECE 435 – Network Engineering

Lecture 20

Vince Weaver

`http://web.eece.maine.edu/~vweaver`

`vincent.weaver@maine.edu`


13 April 2021

Announcements

- Don't forget Project status reports
- Thursday (the 15th) is a reading day, no lecture
- HW#10 will be posted



Wireless



Why Wireless?

- Pros
 - Use anywhere
 - No wires
- Cons
 - Less reliability, noise
 - Less power availability
 - Less security



Wireless LAN

- What does WiFi mean? Nothing really.
- 802.11. Started in 1990, no standard until 1997
- Operates in fixed ISM bands
 - Industrial/Scientific/Medical, no license needed
 - 900MHz, 2.4GHz, 5GHz
 - What issues come up with these bands?
Microwave oven? Cordless phones, Bluetooth
 - Until 2002 ISM usage had to be spread spectrum
 - Up to 1W transmission power (50mW typical)



Wireless LAN Standards

- All of the various 802.11 have been sort of merged together, but people use the old letters out of habit



802.11 (1997)

- Original 802.11 (1997) 1 or 2MBps, 2.4GHz, three implementations
 - infrared(?)
 - direct-sequence spread spectrum (DSSS)
Takes a signal and spreads it along a wider frequency band but adding pseudo-random noise, then subtracting out at the other side.
 - frequency-hopping spread spectrum (FHSS)
rapidly switch signal among a bunch of different



frequencies in a pseudo-random fashion. Harder to
jam, causes less interference?
Initial seed, dwell time




802.11b (1999)

- 802.11b (1999) 5.5Mbps and 11Mbps
 - HR-DSSS (High Rate Direct Sequence Spread Spectrum)
 - Walsh-Hadamard codes (error correction)
 - actually came to market before 802.11a
 - In the 2.4GHz frequency band, no licensing
 - Various channels, 22MHz wide. Not all available in all countries. Some channels overlap.
 - In the US have channels 1 through 11, but 1, 6, 11



are only non-overlapping ones




802.11a (1999)

- 802.11a (1999) 1.5 - 54Mbps
 - Not compatible with B, 54Mbps in 5GHz band
 - 5GHz less crowded, but signal doesn't go as far (7x less than b)
 - OFDM (Orthogonal Frequency Division Multiplexing)
Data is sent on multiple channels in parallel
 - 52 channels: 48 data channels 4 syc




802.11g (2003)

- 802.11g (2003) 54Mbps, 2.4GHz
 - Uses OFDM like 802.11a, but in the 2.4GHz band
 - Backward compatible with b, which slows it down



802.11n (2009)

- 802.11n (2009) 54Mbps - 600Mbps
 - MIMO (multiple input/multiple output antennas)
 - Can do spatial multiplexing, two antennas broadcast on same frequency by aiming signal




More 802.11 variants

- 802.11ac – wider channels, 256 QAM modulation, MU-MIMO (multi-user MIMO), 7Gbps
- 802.11ad – 7Gbps, 60GHz freq
- 802.11af – white wi-fi, super wi-fi, operates in vacant UHF/VHF TV bands. Receiver uses GPS to find out where it is and what channels are free
- 802.11ax – Wifi6, high efficiency?
- Many more



Wireless Frames

FC	Duration	Addr 1	Addr 2	Addr 3	SEQ	Addr 4	Body	FCS
2	2	6	6	6	2	6	0-2312	4




Wireless Frames – Frame Control (FC)

- Frame Control (2 bytes)
 - Protocol Version (2 bits) [only 0 in practice]
 - Type (2 bits): data, control, management
 - Subtype (4 bits) [rts,cts]
 - ToDS/FromDS(1,1) (going to or from the cell)
 - MF (1) more fragments to follow
 - Retry(1)
 - Power Management(1) (into or out of sleep)
 - More(1) [more coming]




- W(1) or Protection: WEP [encryption]
- O(1) frames must be in-order




Wireless Frames – Duration

- Duration/ID (2 bytes) – how long will occupy channel



Wireless Frames – Addresses

- Addr1 (6 bytes) Receiver
- Addr2 (6 bytes) Transmitter
- Addr3 (6 bytes) Base Station Source?
- Address4 (6 bytes) Base Station Dest?
- Addr3/Addr4 optional, usually if bridge.



Wireless Frames – Sequence/Fragment

- Sequence control (2 bytes) Frame (12) and fragment (4)



Wireless Frames – Body

- Frame body (0-2312)




Wireless Frames – CRC

- FCS CRC (4 bytes)



Wireless Frame Types

- Management frames: similar to data frame, restricted to one cell
- Control frames: Short, only two addresses, no data, no sequence, often just RTS/CTS/ACK



Wireless Network Topology

- Ad-hoc mode – peer to peer
- Distribution / Infrastructure mode – many to access point (AP) which has a wired connection
- In infrastructure mode all access goes through the AP




Service Sets

- A basic service set (BSS) is a group of nodes that all recognize each other
- An extended service set (ESS) is a group of overlapping BSSes with APs that are connected together
- An AP keeps the BSSes in line by periodically transmitting beacon frames



802.11 – Why not just Ethernet over the Air


- Hidden station/terminal problem A in range of B, B in range of C, but A cannot see C. If A and C transmit at same time, they'll not get collision, only way of knowing is if not get ACK.



- Exposed station problem. A and C not overlap, but B



does not know this so it sees A transmitted to D and doesn't transmit to B even though it wouldn't cause collision.



- To deal with this, Distributed Coordination Function (DCF) and point coordination function (PCF)



DCF – Distributed Coordination Function

- No central control
- Carrier Sense Multiple Access with Collision Avoidance (CSMA/CA)
- Different from Ethernet CSMA/CD (D=detection)
- Every time ready to transmit, looks to see if can transmit (listen to see if channel clear)
- If clear, waits DIFS (inter frame) time and transmits
- If busy, waits until clear. Then it will wait a random



backoff time before starting. Why? Multiple transmitters might have all been waiting and they would all instantly collide once clear.

- There is a short inter-frame interval (SIFS) which gives time for receiver to transmit an ACK packet.
- If source does not get an ACK, then it backs off and retries
- DCF not optimal, can take 60us to transmit ACK, whereas a 54MB connection could have send 3k of data in same time.



DCF: RTS/CTS Mode

- Optional (rarely used) RTS/CTS mode
 - Before sending data, sends short RTS (request to send) packet
 - Receiver responds with short CTS (clear to send)
 - Data only sent if CTS sent properly
 - All stations can see both CTS *and* RTS, this and hopefully avoids collisions.
 - There's a duration field too to hint how long it will take




- ACK at end



DCF: Fragmentation

- Fragmentation – the longer the packet, the more likely it is to lose bits to interference. So split things up into smaller chunks likely to get through



DCF: PCF – Point Coordination Function

- Also rarely used
- PCF provides central control. A point coordinator in the AP periodically transmits a beacon to announce a contention-free period (CFP). Stations keep quiet.
- Sort of like time-division multiplexing
- Guaranteed a certain fraction of bandwidth h
- For power saving, base station can tell receiver to go to sleep, and buffer packets for it until wakes up
- Can combine PCF and DCF in same cell.



Does my router use PCF or DCF

- It appears that most use DCF, PCF is somewhat uncommon
- There is 802.11e which enhances this to Enhanced distributed channel access (EDCA)
- Introduces HCF (Hybrid Coordination Function)
- Still most are using DCF



Reliability

- Wireless can be noisy and unreliable
- What do you do if there's packet loss?
 - Send slower
 - Send shorter frames
 - Fragment frames



802.11e QoS

- Leaves idle time before sending next frame
- Different sizes for different traffic
- DIFS – DCF inter-frame spacing
 - SIFS – short (control frames)
 - AIFS1 – Arbitrary (high priority)
 - DIFS – regular DIFS
 - AIFS4 – low priority
 - EIFS – extended, for errors
- TXOP – transmission opportunity



- Usually fixed number of frames so faster devices held back
- Instead, provide equal airtime rather than equal frames



Power Saving

- Important for mobile devices
- AP beacon frames from AP every 100ms
- Can indicate you want power saving, then go to sleep, on next beacon wake up and notice from beacon if data available to read (AP will buffer)
- APSD – auto power-save, AP will buffer frames until device sends something, send buffered data knowing it's awake



Wireless Services

Must provide 9 services

- intracell for dealing with things outside of a cell
 - Association – allow stations to connect to base stations. When arriving announce its identity and capability
 - Disassociation – either side may break the association, should do it before shutting down
 - Reassociation – can change preferred base station, useful for handover (but best-effort)




- Distribution – determines best way to route frames
- Integration – in case frame needs to be sent through a non-802.11 network
- Intercell
 - Authentication – check password
 - Deauthentication – to leave network
 - Privacy – encryption
 - Data delivery – modeled on Ethernet, no guarantees frames will get in



Encryption

- Important as anyone can eavesdrop, even from a distance
- <https://arstechnica.com/gadgets/2019/03/802-ele>



WEP (obsolete)

- WEP – Wired Equivalent Privacy
 - Used RC4 and CRC32
 - Deprecated 2004
 - Meant to be 64 bit, originally 40 but due to export limitations
 - Later 128-bit. Can enter in hex or ASCII chars
 - Can be cracked fairly quickly these days (10 mins on a laptop)



WPA (obsolete)

- WPA – Wi-Fi Protected Access (WPA)
 - 802.11i – Temporal Key Integrity Protocol (TKIP)
 - 64 or 128 bit encryption key
 - TKIP replace CRC, harder to crack, RC4
 - WPA-personal Pre-shared key, AKA the password. 128 bits derived from 256 bits. If ASCII, PBKDF2 applied and then SSID used as salt (to prevent rainbow tables)
 - WPA-enterprise is more complicated key setup



WPA2

- WPA2 Wi-Fi Protected Access II (WPA2)
- IEEE 802.11i-2004
 - 4-way handshake (recent issues with that on many Linux machines), Ironically had issues for too closely following IEEE standard
 - AES?
- Was broke in 2017, have to do with key exchange?



WPA3

- WPA3 – 2018
 - 802.11-2016
 - Replaces PSK (pre-shared key exchange) with SAE
 - Simultaneous Authentication of Equals instead of pre-shared key
- Supposed to help with weak passwords, and also configuring devices without displays



Authenticated

- Three states: not authenticated, authenticated but not associated, authenticated and associated
- device sends probe requests. Advertise data rates and what version of 802.11 supported. BSSID of ff:ff:ff:ff:ff:ff so all access points that hear it will respond
- if an access point (AP) supports a common data rate, it will respond with SSID, data rate, encryption mode, etc
- device chooses an access point and authenticates.



Originally this would have been WEP, but deprecated so often happens in open and usually succeeds. Device sends a 802.11 open authentication frame, seq 0x01

- AP responds saying open with seq 0x02
- if AP receives frames other than auth or probe from device, responds with a deauth to make it start over
- A device can be authenticated to multiple APs but only associated with one
- device determines who to associate with and requests



- AP responds and creates association ID
- once associated then WPA/WPA2 has to happen still before data can flow



Security Issues

- Packet sniffing
- Easier to tap into a network undetected. Long range antennas
- Malicious association – go into an area with own access point that machines will connect to
- MAC spoofing, set your MAC to an existing machines
- Denial of Service – flood the router so it can't respond



- Deauthentication attack— continually spoof an "I'm leaving" packet from all MAC addresses on network
- Hide you SSID? How effective is that?
- Encryption breaking, see long list of issues on WPA wikipedia page



Transmission Power

- 802.11b signal typically around 32mW
- Often use dBmW (often shorted dBm) where
0dBm=1mW
- 1dBm = 0.001258925W
- Convert -68 dBm to Watts
 - $P = 1W * 10^{P_{dBm}/10} / 1000$
 - -68 dBm = 160pW
- Convert 1W to dBm



- $P_{dBm} = 10 * \log_{10}(1000 * P_W / 1W)$
- $1W = 30dBm$
- Juno space probe (13 Oct 2016)
 - 8.4GHz, received -135.75dBm ($2.7e-20kW$) 18kb/s



Channels

- 802.11b, DSSS 2.4GHz, 2412MHz as first channel, 14 channels 5MHz apart 1-14.
- 802.11g same as 802.11b when talking to b, but a modes when talking to other g
- 802.11a 5GHz band, channels 1-199 starting at 5005MHz 5MHz apart
- CSM/CA – uses RTS/CTS. 802.11g needs to do this if 802.11b present, slowing things down 20-50%



Linux Interface

- iwconfig
- iwlist scanning

```
wlan0      IEEE 802.11abg  ESSID:"Whatever"
           Mode:Managed  Frequency:2.452 GHz
                        Access Point: 00:1C:10:11:B4:C6
           Bit Rate=54 Mb/s   Tx-Power=200 dBm
           Retry short limit:7   RTS thr:off   Fragment thr:off
           Encryption key:XXXXX
           Power Management:off
           Link Quality=42/70   Signal level=-68 dBm
           Rx invalid nwid:0   Rx invalid crypt:0   Rx invalid frag:0
           Tx excessive retries:0   Invalid misc:0   Missed beacon:0
```



Bluetooth

- Personal Area Network (PAN)



Bluetooth Applications

- Headsets
- Wireless controllers (Wii, PS3)



Bluetooth

- 1994 Ericsson. With IBM, Intel, Nokia and Toshiba formed a SIG.
- Named after Harald Blaatand (Bluetooth II (940-981) a Viking king who “united” (conquered) Denmark and Norway. Unite various standards.
- Symbol is runes for HB.
- Get rid of cables, specifically serial cables
- Interferes with 802.11
- IEEE came in and decided to take standard and make it



802.15.1 but no longer maintains it



Bluetooth Architecture

- Basic unit: piconet, master node and up to seven *active* slave nodes within 10m
- Many can exist in an area, and can be connected by a bridge. Connected piconets are called a scatternet
- There can also be up to 255 “parked” nodes in a picnoet
- When parked, can only respond to activation on beacon
- Hold and siff?



- Slaves designed to be cheap, so dumb. Master is smart and runs them. slave/slave communication not possible
- Master broadcasts clock 312.5us. Master transmits in even, slave in odd.



Bluetooth Applications – Profiles

Bluetooth V1.1 has 13 different application protocols.

- Required
 - generic access – link management
 - service discovery – discovering services
- - Serial port
 - Object exchange
- Networking
 - LAN access
 - Dial-up



- Fax
- Telephony
 - Cordless phone
 - Intercom
 - Headset
- File exchange
 - Object push
 - File transfer
 - Synchronization



Bluetooth Layering

- Radio layer
 - 2.4GHz, 10 meters. 79 channels of 1MHz.
 - Frequency shift keying, 1 Mbps but consumed by overhead
 - Frequency hopping spread spectrum, 1600 hops/sec dwell of 625 usec. All nodes in piconet hop at once, with master controlling this (PRNG) 1,3, or 5 slots/packet
 - Interferes with 802.11. Bluetooth hops faster so causes



more trouble.

- power output class: 100mW class 1, 2.5mW class 2, 1mW class 3.
- Baseband layer
 - Asynchronous Connection-less link (ACL) packet-switch data at irregular info, no guarantees. one per slice
 - Synchronous Connection Oriented (SCO) – for real time data.
 - Three per slave. Error correction. Each can send 64kpbs PCM audio



- L2CAP layer
 - accept packets of 64kB and break into frames.
 - Handles multiplexing.



Bluetooth Frames

- Several different formats
- 72 bits access (identify master, as can be in range of multiple)
- 54 bit header
 - (addr(3) frame type(4), flow [buffer full](1), Ack (1) seq(1) checksum(8)
 - This is repeated 3 times.
 - Majority wins (redundancy, cheap small protocol)
- Data 0-2744 bits. SCO always 240 bits.



Bluetooth 1.1 (2002)

- First stable version
- Gaussian Freq-shift Keying (GFSK). Smooths signal instead of abrupt 1/0 transition
- 1Mbps peak in theory



Bluetooth 1.2

- Adaptive frequency hopping, skip busy frequencies
- Up to 721kbps
- eSCO allow retransmitting corrupted packets, at expense of audio latency
- HCI host controller interface, three wire



Bluetooth 2.0 (2004)

- 2.0
 - EDR = Enhanced Data Rate
 - BR/EDR 2 and 3Mbps
 - $\pi/4$ DQPSK – differential quadrature phase-shift keying
- 2.1
 - Secure simple pairing
 - Extended inquiry response



Bluetooth 3.0 (2009)

- Up to 25Mbps “HS” (high speed)
- Alternative MAC, bluetooth set up connection but 802.11 used to transmit data?



Bluetooth 4.0 (Bluetooth Low Energy) (2010)

- Entirely new stack, designed for low power rapid setup links
- 40 2MHz channels, 1Mbit/s
- Max power 10mW
- Not backwards compatible, but same frequency range
- New profiles



Bluetooth 5.0 (2017)

- Internet of things
- 2MBit/s



Setting up Connections

- In discoverable mode, will transmit name, class, services, etc on demand
- Has unique 48 bit number but that's rarely seen
- Bonding/Pairing – to avoid people stealing info from your device, require some sort of user interaction to connect for the first time. Before 2.1 it was a 16-byte pin code
- Secure simple pairing, pub key crypto



Security

- Prior to 2.1 security can be turned off, and only good for 23.5 hours



Linux Bluetooth

- Competing implementations (bluez, Affix)
- Install bluez
- bluetoothctl

```
[NEW] Controller B8:27:EB:05:9D:BB pi3 [default]
[bluetooth]# exit
[DEL] Controller B8:27:EB:05:9D:BB pi3 [default]
root@pi3:/home/vince# bluetoothctl
[NEW] Controller B8:27:EB:05:9D:BB pi3 [default]
[bluetooth]# scan on
```



```
Discovery started
[CHG] Controller B8:27:EB:05:9D:BB Discovering: yes
[bluetooth]# power on
Changing power on succeeded
[bluetooth]# scan on
Failed to start discovery: org.bluez.Error.InProgress
[bluetooth]# scan on
Failed to start discovery: org.bluez.Error.InProgress
[NEW] Device 64:8A:44:9D:DC:FD 64-8A-44-9D-DC-FD
[NEW] Device D3:E8:9D:CA:71:63 D3-E8-9D-CA-71-63
[CHG] Device D3:E8:9D:CA:71:63 RSSI: -89
```

