

ECE 471 – Embedded Systems

Lecture 9

Vince Weaver

<http://www.eece.maine.edu/~vweaver>

vincent.weaver@maine.edu

29 September 2015

Announcements

- HW#4 was posted.
- Using FILE stream notes:
 - Be sure to either open/close or rewind after each read.
 - Be careful if trying to open for read *and* write "r+"
 - Check error on fprintf? Usually you don't bother.
 - If fprintf want newline or it will be buffered.
- Permissions!
 - Unless your user is configured to have gpio permissions



you'll have to run as root. raspbian there's a "gpio" group which has permissions `sudo addgroup vince gpio`

This might not work if you have an older version of Raspbian



Homework 3

- Comment code! Fix wrong comments! My sample code had some out-of date comments (referencing “eax”)
- `print_number()` code
 - No conversion to binary, number is in binary in register.
 - The divide by 10 code is almost more interesting.
 - Good to be able to look at code and see what doing. Reverse engineering, but also debugging code you don't have the source to.

```
print_number:
```



```

    push    {r10,LR}        // Save registers
    ldr     r10,=buffer     // what does = mean?  where is buffer?
    add     r10,r10,#10     // why 10 bytes?

divide:
    bl     divide_by_10     // why no div instruction?
    add     r8,r8,#0x30     // why add 0x30?
    strb   r8,[r10],#-1    // why moving backwards?
    adds   r0,r7,#0        //
    bne    divide          //

write_out:
    add     r1,r10,#1       // why adjust pointer?

    bl     print_string    //

    pop     {r10,LR}       //

    mov    pc,lr           //

```

- strlen code example, many ways to do this



```
        mov        r2 , #0
print_loop :
        ldrb       r0 , [ r1 , r2 ]
        add        r2 , r2 , #1
        cmp        r0 , #0
        bne        print_loop
```

- THUMB code should have been less.

You need to run `strip` on this to see it. Why?

Debug info, including extra thumb debug as well as the longer filename.



You can use `readelf -a` and `readelf -s` to see the space the various segments take up.

arch	unstripped	stripped
arm32	1444	624
thumb	1460	600
thumb2		596
C	6k	2k

You would think THUMB2 would be much smaller, but the assembler makes some poor decisions about wide/narrow instructions.



C code is larger, but also remember to include the C library:

```
ls -lart /lib/arm-linux-gnueabi/libc-2.19.so  
-rwxr-xr-x 2 root root 1226392 Sep  6 01:57 /lib/arm-linux-gnueabi/libc-2.19.so
```

There are embedded C libraries, musl, newlib, uclibc, which are much smaller and often used in embedded systems.

- Illegal instruction error usually because there are *two* calls to print string, need to make sure both are blx
- cal. Missing days. Julian to Gregorian calendar. People



sad who paid weekly but paid rent monthly.



Debouncing!

- Pull-up / Pull-down resistor. Why?
- Noisy switches, have to debounce
- Manual, no built-in debounce like on STM32L



Bypassing Linux to hit hardware directly

- Linux does not support things like pullups, but people have written code that will poke the relevant bits directly.
- WiringPi



Why Use an Operating System?

- Provides Layers of Abstraction
 - Abstract hardware: hide hardware differences. same hardware interface for classes of hardware (things like video cameras, disks, keyboards, etc) despite differing implementation details
 - Abstract software: with VM get linear address space, same system calls on all systems
 - Abstraction comes at a cost. Higher overhead, unknown timing



- Multi-tasking / Multi-user
- Security, permissions (Linus dial out onto /dev/hda)
- Common code in kernel and libraries, no need to re-invent



What's included with an OS

- kernel / drivers – Linux definition
- also system libraries – Solaris definition
- low-level utils / software / GUI – Windows definition
Web Browser included?
- Linux usually makes distinction between the OS Kernel and distribution. OSX/Windows usually doesn't.



Operating Systems Types

- Monolithic kernel – everything in one big address space. Something goes wrong, lose it all. Faster
- Microkernel – separate parts that communicate by message passing. can restart independently. Slower.
- Microkernels were supposed to take over the world. Didn't happen. (GNU Hurd?)
- Famous Torvalds (Linux) vs Tannenbaum (Minix) flamewar



Common Desktop/Server Operating Systems

- Windows
- OSX
- Linux
- FreeBSD / NetBSD / OpenBSD
- UNIX (Irix/Solaris/AIX/etc.)
- BeOS/Haiku



Embedded Operating Systems

- Microsoft WinCE, Windows Mobile
- Linux / Android
- VXworks – realtime OS, used on many space probes
- Apple iOS
- QNX – realtime microkernel UNIX-like OS, owned by Blackberry now
- Cisco iOS



Embedded Linux Distributions

- linaro – consortium that work on ARM software
- openwrt – small distro initially designed for wireless routers
- yocto – Linux Foundation sponsored embedded distro
- maemo – embedded distro originally by Nokia (obsolete)
- MeeGo – continuation of maemo, also obsolete



- Tizen – Follow up on MeeGo, by Samsung and Intel
- Ångstrom – Merger of various projects
- And many others. It's very easy to put together a Linux distribution



Linux/UNIX History

- UNIX invented early 70s at Bell Labs
- Widely distributed by academics
- Berkeley makes their own BSD version
- By the 90s many companies selling UNIX workstations. Expensive.
- Linus Torvalds in 1991 wanted own UNIX-like OS. Minix (which he used for development) limited to academic use



and non-free. The various BSDs caught up in lawsuit with AT&T. So he wrote his own.

